


## Control Panel Itemised



Solenoid valve: rainwater from pump in underground tank.

Solenoid valve: flush back to storage tank


Solenoid valve: mains water backup.

Manual valve: mains water during long power cut

Control panel with buttons and indicator lights covering micro-processors.

12 volt supply from wall-socket-mounted mains converter.

Leads from header tank sensors.



(Patent pending)

**RainDirector®**

www.rainwaterharvesting.co.uk

RainWater Harvesting

Rain filling			Normal
Mains filling			Mains Water Only
Mains water only			Holiday Setting
Holiday mode			Flush through
Flush mode			
Mains water not working (red)			
Power On			